




| Description | Scheme | Marking on legend | Marking on push button | Model | Dimension |
|--|--------|-------------------|------------------------|-------------|-----------|
| 1 green flush pushbutton spring return | | Start | — | GB2-B101H29 | |
| | | — | ■ | GB2-B102 | |
| | | — | Start | GB2-B103 | |
| | | — | — | GB2-B101 | |
| 1 red flush pushbutton spring return | | Stop | — | GB2-B111H29 | |
| | | — | Stop | GB2-B114 | |
| 1 red projectint pushbutton spring return | | — | O | GB2-B112 | |
| 1 red mushroom head pushbutton φ 40mm, spring return | | Emergency stop | — | GB2-B164H29 | |
| | | — | — | GB2-B164 | |
| 1 red mushroom head pushbutton, φ 40mm, latching Turn to release | | | Red | GB2-J174 | |
| | | | Red | GB2-J174H29 | |


GB2 series control station

1



| Description | Scheme | Marking on legend | Marking on push button | Model | Dimension |
|---|----------------|-------------------|------------------------|-------------|-----------|
| 1 red mushroom head pushbutton, ϕ 40mm, latching Key release (Key n° 455) | N/O | | Red | GB2-J184 | |
| | | | Red | GB2-J188H29 | |
| 1 selector switch 2-position stay put standard black handle | N/C | Stop Start | — | GB2-B132H29 | |
| | | | — | GB2-B134H29 | |
| 1 selector switch key operated (Ronis Key n° 455) 2-position stay put Key withdraw from left position | N/C | Stop Start | — | GB2-B142H29 | |
| | | | — | GB2-B144H29 | |
| 2 spring return push button 1 flush green 1 flush red | N/O + NC | Open close | — | GB2-B241H29 | |
| | | Stop start | — | GB2-B211H29 | |
| | | — | | GB2-B213 | |
| | | — | Stop Start | GB2-B215 | |
| 2 spring return pushbutton 1 flush black (white arrow) | N/O + NC | — | | GB2-B222 | |
| | | — | | GB2-B223 | |

GB2 series control station



| Description | Scheme | Marking on legend | Marking on push button | Model | Dimension |
|---|--------|-------------------|------------------------|-------------|-----------|
| 1 red pilot light, Direct supplied < 130V Bulb not supplied+ 2 spring return pushbuttons 1 flush green 1 flush red | | Stop | — | GB2-B361H29 | |
| | | Start | ○ | GB2-B363 | |
| | | — | Stop | GB2-B366 | |
| | | Start | — | | |
| 1 red pilot light, 220/250V Supply direct through resistor BA9S-130V bulb supplied 2 spring return pushbuttons 1 flush red 1 flush green | | Stop | — | GB2-B371H29 | |
| | | Start | ○ | GB2-B373 | |
| | | — | Stop | GB2-B376 | |
| | | Start | — | | |
| 3 spring return pushbuttons 1 flush green 1 flush red 1 flush green | | Open | — | GB2-B341H29 | |
| | | Stop | — | | |
| | | Close | — | | |
| | | Forward | — | GB2-B311H29 | |
| | | Stop | — | | |
| | | Reverse | — | GB2-B331H29 | |
| 3 spring return pushbuttons 1 flush green (black arrow) 1 flush red 1 flush black (white arrow) | | — | ↑ | GB2-B324 | |
| | | — | ↓ | GB2-B334 | |
| | | — | ↑ | | |
| | | — | ↓ | | |
| 3 spring return pushbuttons 1 flush green 1 flush red 1 flush green | | — | ○ | GB2-B339 | |
| | | — | ○ | | |
| | | Up | — | GB2-B321H29 | |
| | | Stop | — | | |
| Down | — | | | | |